

## Introduction

The SPC582B-DIS is a low-cost development board to evaluate and develop applications with the microcontroller SPC582B60E1 in eTQFP 64-pin package.

This document describes the hardware architecture of the SPC582B-DIS Discovery board and in which way the jumpers can be set to enable specific functions.

## Contents

<b>1</b>	<b>SPC582B-DIS Discovery board with SPC582B60E1</b>	<b>5</b>
1.1	SPC582B-DIS Discovery board	5
<b>2</b>	<b>Hardware overview</b>	<b>7</b>
2.1	Power supply section	7
2.1.1	Jumpers configuration cable	7
2.1.2	Voltage regulators and jumpers	7
2.2	Microcontroller power management	9
2.3	Integrated Programmer/Debugger	9
2.4	Crystal oscillator	11
2.5	Reset circuit	12
2.6	User LEDs, User Button	12
2.7	Connectors	13
2.7.1	Arduino connectors	13
2.7.2	Extended Connectors (I/O Headers)	15
2.7.3	BT Module Connector	19
2.7.4	JTAG Connector	19
<b>Appendix A</b>	<b>Board layout</b>	<b>20</b>
A.1	PCB layout	20
<b>Revision history</b>		<b>22</b>

## List of tables

Table 1.	Power source and jumpers configuration . . . . .	7
Table 2.	Programmer/Debugger - Jumpers setting . . . . .	10
Table 3.	Crystal oscillator - jumper configuration . . . . .	12
Table 4.	Reset circuit - jumpers configuration . . . . .	12
Table 5.	CN6 - Arduino UNO-R3 Power . . . . .	13
Table 6.	CN8 - Arduino UNO-R3 Analog Input . . . . .	14
Table 7.	CN5 - Arduino UNO-R3 Digital PWM (D15÷D8) . . . . .	14
Table 8.	CN9 - Arduino UNO-R3 Digital PWM (D7÷D0) . . . . .	15
Table 9.	CN7 - Extended Connectors (I/O Headers) . . . . .	15
Table 10.	CN10 - Extended Connectors (I/O Headers) . . . . .	16
Table 11.	CN2 - BT Module Connector . . . . .	19
Table 12.	CN1 - JTAG Connector . . . . .	19
Table 13.	Document revision history . . . . .	22

## List of figures

Figure 1.	SPC582B-DIS.....	5
Figure 2.	USB Port - 5 V input .....	8
Figure 3.	+5 V regulator (external PSU) and 5 V selector (SB17-SB27) .....	8
Figure 4.	+3.3 V voltage regulator and +3.3 V selector (SB26) .....	8
Figure 5.	E3V3 and E5V jumpers .....	9
Figure 6.	Microcontroller power management - Jumper setting.....	9
Figure 7.	PLS Integrated Programmer/Debugger (part I) .....	10
Figure 8.	PLS Integrated Programmer/Debugger (part II - Level shifters and EEPROM) .....	11
Figure 9.	PLS Integrated Programmer/Debugger (part III - Jumper configuration) .....	11
Figure 10.	Crystal oscillator (default configuration) .....	11
Figure 11.	Reset circuit .....	12
Figure 12.	User LEDs .....	13
Figure 13.	User Push-Button .....	13
Figure 14.	PCB Layout - Top Side.....	20
Figure 15.	PCB Layout - Bottom Side .....	21


# 1 SPC582B-DIS Discovery board with SPC582B60E1

## 1.1 SPC582B-DIS Discovery board

The SPC582B-DIS Discovery board is an evaluation tool supporting STMicroelectronics SPC582B60E1, a high performance e200z2 single core 32-bit Power Architecture technology CPU 80MHz, 1088 KB (1024 KB code flash + 64 KB data flash) 96 KB SRAM in an eTQFP64 package.

The SPC582B-DIS allows full access to peripherals such as DSPI, LINFlexD, ISO CAN-FD. The new features satisfy the ASIL-B requirements.

**Figure 1. SPC582B-DIS**



The board integrates a PLS programmer/debugger that allows debugging and programming the microcontroller via USB cable. In addition, it allows enabling a USART communication channel (USB Virtual COM port).

Dedicated connectors allow plugging shields Arduino UNO-compatible; this feature makes it easy to expand the functionality of the SPC582B-DIS.

All CPUs pins are connected to two-pin arrays; this solution simplifies the debug activity as well as it reduces the effort to connect the SPC582B-DIS to the final user application board.

A standard 2x7pin JTAG port is available<sup>(a)</sup> to program and debug the microcontroller by using third part tools.

---

a. The male connector (2x7 pins) is not assembled

## 2 Hardware overview

### 2.1 Power supply section

SPC582B-DIS can be supplied by using some DC sources, setting some jumpers properly:

- by the host PC through the USB cable (+5 V; this is the default configuration);
- by an external source connected to VIN pin (CN6 pin 8, CN7 pin 8) (7÷12V<sup>(b)</sup>)
- by an external source connected to E5V (CN6 pin 5, CN7 pin 17 and CN10 pin 8)
- by an external source connected both to E3V3 (CN6 pin 4 and CN7 pin 15) and to E5V

The external source can be a PSU, or the user application. The external sources or the PSUs connected to the board must be SELV<sup>(c)</sup> compliant, self-protected and with limited current capability.

#### 2.1.1 Jumpers configuration cable

**Table 1. Power source and jumpers configuration**

	Jumper configuration				
Power Source	+5V		+3.3V	E5V	E3V3
Jumper	SB17	SB27	SB26	SB14	SB6
PCB - USB Cable	Close	Open	Close	Close	Close
External source - VIN	Open	Close	Close	Close	Close
External source - E5V	Open	Open	Close	Close	Close
External source - E3V3 and E5V	Open	Open	Open	Close	Close

#### 2.1.2 Voltage regulators and jumpers

This paragraph depicts the power supply section and the how to configure the jumpers.

LD1 monitors the +5 V supply. U2 and U3 are linear regulator; the output voltage is 5 V and 3.3 V respectively.

- 
- b. The maximum input voltage level is limited by the thermal dissipation of the linear regulators; the input voltage level must be selected and limited in according to the microcontroller current absorption.
  - c. “SELV” means “Safety Extra-Low Voltage”.

Figure 2. USB Port - 5 V input




Figure 3. +5 V regulator (external PSU) and 5 V selector (SB17-SB27)







Figure 4. +3.3 V voltage regulator and +3.3 V selector (SB26)



**Figure 5. E3V3 and E5V jumpers**

## 2.2 Microcontroller power management

JP3 and JP4 set the supply voltage levels of VDD\_HV\_IO\_MAIN and VDD\_HV\_ADV.

**Figure 6. Microcontroller power management - Jumper setting**

## 2.3 Integrated Programmer/Debugger

The integrated programmer/debugger allows the user to program the microcontroller and debug the software applications; it is based on the UDE PLS software.

The debugger serial number is reported on the label applied on the board (bottom side).

The integrated debugger SW is accessible via ST's free integrated development environment, SPC5Studio ([www.st.com/spc5studio](http://www.st.com/spc5studio)). To download the debugger software and to activate license refer to the PLS website.

A JTAG port allows connecting further HW/SW tools to program and debug the microcontroller<sup>(d)</sup>. U106 can be configured to establish a serial communication port; pin 38


(Tx), pin 39 (Rx) and two level shifters implement this feature. [Table 2](#) shows how to set the jumpers.

Note: The board comes with the integrated programmer enabled.



**Table 2. Programmer/Debugger - Jumpers setting**

	SB23	SB8	SB9	SB10	SB11	SB12	SB13	SB31	SB32
PLS Integrated Programmer	Close								
External JTAG Programmer	Open								

**Figure 7. PLS Integrated Programmer/Debugger (part I)**




d. The JTAG connector (2x7 male pin array) is not assembled.

**Figure 8. PLS Integrated Programmer/Debugger (part II - Level shifters and EEPROM)****Figure 9. PLS Integrated Programmer/Debugger (part III - Jumper configuration)**

## 2.4 Crystal oscillator

The board accepts different clock sources. In the default HW configuration a 40MHz crystal (X2) is connected to the microcontroller oscillator pins.

**Figure 10. Crystal oscillator (default configuration)**

The jumpers SB1, SB2 and SB3 allow enabling further input clock as described in [Table 3](#).

**Table 3. Crystal oscillator - jumper configuration**

	SB1	SB2	SB3
<b>Crystal (40MHz)</b>	Open	Close	Open
<b>Ext Clock</b>	Close	Open	Open


## 2.5 Reset circuit

[Figure 11](#) shows the reset circuit; it generates a sharp signal to reset the microcontroller when the pushbutton SW1 is pushed.

SW1 triggers the STM6315RB-2.63V and it generates reset pulse (active low signal); D2 is turned on when the reset pulse is generated. The solder jumper SB16 allows to disconnect PORST and NRST signals (in the default configuration it is closed).

The internal reset generator can be disabled and the reset signal can be provided by an external source connected to CN6 pin3; to implement this configuration SB15 should be removed.

**Figure 11. Reset circuit**




**Table 4. Reset circuit - jumpers configuration**


	SB15	SB16
<b>Internal reset circuit</b>	Close	Close
<b>External reset circuit</b>	Open	Close

## 2.6 User LEDs, User Button

In the SPC582B-DIS board three LEDs are available for user purposes; see [Figure 12](#). The jumpers SB18, SB19 and SB20 allow disconnecting the anode of each LED and then let the user to reserve these pins for a different purpose.

**Figure 12. User LEDs**

The pushbutton SW2 is reserved for user purpose (see [Figure 13](#)). If the jumper SB21 is left open, PF2 port is available for a different purpose.

**Figure 13. User Push-Button**

## 2.7 Connectors

### 2.7.1 Arduino connectors

**Table 5. CN6 - Arduino UNO-R3 Power**

Arduino UnoR3 Power	Connector CN6	
	CN6 Pin	Function / Signal
-	1	-
IOREF (3V3)	2	VDD_HV_IO_MAIN (3V3)
NRST	3	NRST
3V3	4	E3V3
5V	5	E5V









**Table 10. CN10 - Extended Connectors (I/O Headers) (continued)**

Signal	Connector CN10						
	CN10 Pin	uC Port	uC Pin	Function	Alternate Function (1)	Alternate Function (2)	Alternate Function (2)
D4 (CN9)	29	PC13	61	UC28	SIN - DSPI_1	M_CAN_1 _TX	
	30	PD0	58	SCK - DSPI_2	UC22	REQ4	
D3 (CN9)	31	PA2	50	LINFlex1 TXD	UC10	INT18	
AGND	32						
D2 (CN9)	33	PA1	53	LINFlex1 RXD	UC11	INT19	
	34	PG10	23	AN[55]			
D1 (CN9)	35	PC4	3	LINFlex2 TXD	UC6		
nc	36						
D0 (CN9)	37	PC3	4	LINFlex2 RXD	UC7		
nc	38						

### 2.7.3 BT Module Connector

Table 11. CN2 - BT Module Connector

Signal	CN2 Connector				
	CN2 Pin	uC Port	uC Pin	Function	Alternate Function (1)
TXD	1	PC2	5	LINFlexD15 TXD	UC8
RXD	2	PC1	6	LINFlexD15 RXD	UC9
GND	3				
E5V	4				

### 2.7.4 JTAG Connector

Table 12. CN1 - JTAG Connector

CN1 Connector		
CN1 Pin	uC Pin	Function
1	38	TDI
2	-	GND
3	41	TDO
4	-	GND
5	43	TCK
6	-	GND
7	-	NC
8	-	NC
9	45	PORST
10	40	TMS
11	12	VDD_HV_IO
12	-	GND
13		NC
14	42	JCOMP

## Appendix A Board layout

### A.1 PCB layout

Figure 14. PCB Layout - Top Side





Figure 15. PCB Layout - Bottom Side



## Revision history

**Table 13. Document revision history**

Date	Revision	Changes
15-Mar-2017	1	Initial release.
20-Jun-2017	2	Updated <a href="#"><i>Section : Introduction</i></a> .

**IMPORTANT NOTICE – PLEASE READ CAREFULLY**

STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST's terms and conditions of sale in place at the time of order acknowledgement.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of Purchasers' products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2017 STMicroelectronics – All rights reserved

